

CHAPTER 3: SOFTWARE

1. INTRODUCTION


This chapter presents technical information on each of ADAM's software components. Emphasis is placed on AdamNet and the available operating systems. Descriptions of application software are provided as examples to software developers.

Source code listings for EOS and OS_7 can be requested with the form on the last page of this manual.


2. MEMORY MAP AND POWER UP/RESET PROCEDURE

Adam's Z80 microprocessor can address 64K bytes at any one time. The 64K addressable memory space is divided into two 32K sections. Each section may contain one of four memory options. Any one option for lower memory and any one option for upper memory can be selected for the full 64K memory space via port 7FH.

Memory Options for 0 - 7FFFH (lower memory)



Memory Options for 8000H - FFFFH (upper memory)



2.1 Lower Memory Options

SmartWRITER Word Processor ROM - This memory option consists of 32K of SmartWRITER ROM code. A small part of this code, EOS_BOOT, is responsible for system initialization during power up and reset. EOS ROM can also be accessed when this option is selected. See Subsection 4.1, EOS, for further details.

32K Intrinsic RAM - This option is the lower half of the 64K RAM included with every ADAM. DMA transfers to AdamNet can take place only in intrinsic RAM. SmartBASIC and most programs stored on data pack reside in this memory.

32K Expansion RAM - This option is the lower half of the 64K Memory Expander, an optional feature not included with the ADAM system. The 64K Memory Expander increases ADAM's memory to 144K of read/write memory (64K intrinsic, 64K expansion, 16K VRAM).

OS 7 and 24K Intrinsic RAM - This option contains OS_7 and 24K of ADAM's intrinsic RAM. OS_7 is the 8K ROM installed in ColecoVision and ADAM. In Expansion Module #3, this ROM is in the ColecoVision. The description of the 32K Intrinsic RAM also applies to this 24K intrinsic RAM.

2.2 Upper Memory Options

32K Intrinsic RAM - This option is the upper half of the 64K intrinsic RAM included with ADAM. DMA transfers to AdamNet can take place only intrinsic RAM. SmartBASIC and most programs stored on data pack reside in this memory.

Expansion ROM - This memory is provided by an expansion ROM, an optional feature not included in the ADAM system. The expansion ROM is installed in Connector #2 on the Memory and I/O Board. EOS_BOOT checks this connector for valid data before initializing EOS. If valid data is found, the EOS_BOOT code jumps to this ROM.

32K Expansion RAM - This is the upper half of the optional Expansion RAM described for lower memory.

32K Cartridge ROM - This memory option is the cartridge slot on ADAM or ColecoVision, used to execute game cartridges or other cartridge-based software.

2.3 Power Up/Computer Reset Procedure

When Adam powers up or when the computer reset switch is pressed, the MIOC selects SmartWRITER in lower memory and Intrinsic RAM in upper memory. EOS_BOOT executes this procedure:

Check for Expansion ROM. If Expansion ROM exists, jump to Expansion ROM.

Else, initialize EOS and jump to EOS_START

Check for the presence of devices in this order:

- Disk Drive 1
- Disk Drive 2
- Data Pack Drive 1
- Data Pack Drive 2

If a device exists, check for valid data in the device.

Boot and execute code from the first valid device found by loading block 0 to address 0C800H then jumping to 0C800H.

If no valid data is found on any device, execute SmartWRITER.

2.4 Z80 I/O Port Assignments

<u>Port</u>	<u>Description</u>
00H through 1DH	Reserved
1EH	Optional Auto Dialer
1FH	Reserved
20H through 3EH	Reserved
3FH*	Network reset; EOS enable
40H through 4EH	Reserved
4FH	Expansion connector #2
50H through 5DH	Reserved
5EH	Optional Modem Data I/O
5FH	Optional Modem Control Status
60H through 7EH	Reserved
7FH	Memory Map Control
80H through FFH	Reserved for ColecoVision use

*Net reset - The net reset function is performed by setting bit 0 and then resetting bit 0.

*EOS enable - Setting bit 1 enables the EOS ROM. Resetting bit 1 disables EOS ROM. The EOS enable function only affects the SmartWRITER ROMs. To access the EOS ROM, the SmartWRITER ROMs must be selected.

For further details on port assignments, see PORT_COLLECTION in the EOS Source Code Listing.

2.5 Memory Map Control

Software can select the memory configuration by writing to Port 7FH. Data bits D0 and D1 select the lower (0 - 7FFFH) memory option. D2 and D3 select the upper (8000H - FFFFH) memory option. D4 through D7 are reserved for future expansion, and should remain as 0. The value to be written to Port 7FH is obtained from the following tables.

Lower Memory Option Selection

0	0	SmartWRITER ROM and EOS ROM
0	1	32K Intrinsic RAM
1	0	32K Expansion RAM
1	1	OS7 + 24K Intrinsic RAM

Upper Memory Option Selection

0	0	32K Intrinsic RAM
0	1	Expansion ROM
1	0	Expansion RAM
1	1	Cartridge ROM

2.6

Reset Procedures

Adam can be reset in either computer mode or in game mode. When the computer reset switch is pressed, Adam resets to computer mode, according to the power up procedure described in Subsection 2.3.


When the cartridge (or ColecoVision) reset switch is pressed, Adam resets to game mode. 32K of Cartridge ROM are switched into upper memory. OS-7 plus 24K of intrinsic RAM are switched into the lower bank of memory. Refer to Subsection 9.1 for the game mode memory map.

3. ADAMNET

3.1 Introduction

AdamNet is based physically on a shared bus, single master topology, although logically it resembles a token-passing network. The physical design of the network is depicted in Figure 3-1.

FIGURE 3-1: BUS NETWORK



The circles represent nodes (for example, printers or keyboards), which connect to a shared bus, represented by the horizontal line. The network is a four wire bus. The wire definitions are:

- Data
- Reset
- Signal ground
- Power

The network resides in all Adam components. The reset line behaves as a master reset signal to every node attached to the network. A transition on this line causes all attached devices to enter the power-on state, allowing the master to bring sanity to the network during periods of erratic behavior.


Logical Design

Logically, AdamNet resembles a token-passing network. In a token-passing network, the right to talk on the bus is passed from node to node. This right, or "token", allows the node to access the bus and send messages. One node functions as the master of the bus. The master gives the token to other nodes with a regulated frequency.

3.2 Network Master Concept

Conceptually the master is like any other node on the network. Each node contains an IEEE defined Medium Access Control (MAC) layer of software that enables the node to gain access to the network. The MACs in non-master nodes contain a subset of the functions in the master's MAC. Internally all MACs are composed of four loosely coupled logical machines: Node Interface Machine (NIM), Access Control Machine (ACM), Receive Machine (RM) and Transmit Machine (TM).

FIGURE 3-2: MAC Internals



The MAC's version of the Access Control Machine is significantly different from that of the non-master nodes. The NIM, RM and TM components in the master and non-master nodes are basically equivalent. The RM and TM are physical level I/O routines that accept and send data frames.


3.3 Message Philosophy and Definition

AdamNet messages can be divided into two types: commands and responses. Each type can be subdivided into either data or

control sub-types. Commands are messages initiated by the master, while responses are initiated by non-master nodes. The following four possibilities exist:

- command.control
- command.data
- response.control
- response.data


The format of a basic message follows:



Where: a = device address
s = subtype (indicates the nature of the message)


The messages are defined in the following pages.

3.3a. COMMAND.CONTROL (RESET)




a = target address (1..15)
t = RESET (0)

3.3b. COMMAND.CONTROL (STATUS)




a = target address (1..15)
t = STATUS (1)

3.3c. COMMAND.CONTROL (ACK)




a = target address (1..15)
t = ACK (2)

3.3d. COMMAND.CONTROL (CLR)




a = target address (1..15)
t = CLEAR (3)

3.3e. COMMAND.CONTROL (RECEIVE)




a = target address (1..15)
t = RECEIVE (4)

3.3f. COMMAND.CONTROL (CANCEL)




a = target address (1..15)
t = CANCEL (5)

3.3g. COMMAND.DATA (SEND)




a = target address (1..15)
t = SEND (6)
s1,2 = MAX message size.
DATA = data byte
cs = check sum

3.3h. COMMAND.CONTROL (NACK)




a = target address (1..15)
t = NACK (7)

3.3i. RESPONSE.CONTROL (STATUS)




a = source address (1..15)
t = STATUS (8)
x = transmit code: 0 - character mode (0-255)
 1 - block mode
r = reserved
n = device dependent status
l = MAX message size
cs = check sum of bytes 1 - 4

3.3j. RESPONSE.CONTROL (ACK)




a = source address (1..15)
t = ACK (9)

3.3k. RESPONSE.CONTROL (CANCEL)




a = source address (1..15)
t = CANCEL (10)

3.31. RESPONSE.DATA (SEND)



a = source address (1..15)
t = SEND (11)
s1,2 = MAX message size.
DATA = data byte
cs = check sum

3.3m. RESPONSE.CONTROL (NACK)




a = source address (1..15)
t = NACK (12)

3.4 Error Control

Data messages use an exclusive-or checksum to verify the integrity of the data. More specifically, for a $n-1$ byte data stream, an n th byte is added which is equal to the exclusive or'd checksum of the zero'th through the $n-1$ byte of the data stream. This insures that the checksum (exclusive or'd) of the zero'th through the n th byte equals zero.

FIGURE 3-3: ERROR CONTROL



A retry method is implemented by the Master to determine whether the lack of a response from a node is due to either a busy or failure condition.

3.5 Class of Service Concept

Each node is assigned a class of service. Class of service is defined as:

maximum message length
node type

To accept a device onto the network the CPU queries the device with a "COMMAND.CONTROL (STATUS)." In turn, the target device responds with a "RESPONSE.CONTROL (STATUS)" which entails the delivery to the host of a multi-byte package. This package defines to the host the nature and attributes of the responding device.

3.6 Power Up/Initialization

The CPU asks each attached device for its class of service message at power up. The CPU is responsible for associating

a logical unit address to each physical port on the bus. See EOS for device assignments.

3.7 Link Speed

The baud rate is 62.5k. This translates to a bit cell time of 16us. Thus, the time to transmit one byte (including a start and stop bit) is 160us.

3.8 Master Node Interface

AdamNet communicates with the Z80 through a message passing system. The Z80 RAM contains a group of data structures called DCBs (Device Communication Blocks). Every device on AdamNet is associated with a DCB. The structure of a DCB follows:

DCB_CMD_STAT	EQU	0
DCB_BA_LO	EQU	1
DCB_BA_HI	EQU	2
DCB_BUF_LEN_LO	EQU	3
DCB_BUF_LEN_HI	EQU	4
DCB_SEC_NUM_0	EQU	5
DCB_SEC_NUM_1	EQU	6
DCB_SEC_NUM_2	EQU	7
DCB_SEC_NUM_3	EQU	8
DCB_DEV_NUM	EQU	9
*reserved	EQU	10
*reserved	EQU	11
*reserved	EQU	12
*reserved	EQU	13
DCB_RETRY_LO	EQU	14
DCB_RETRY_HI	EQU	15
DCB_ADD_CODE	EQU	16
DCB_MAXL_LO	EQU	17
DCB_MAXL_HI	EQU	18
DCB_DEV_TYPE	EQU	19
DCB_NODE_TYPE	EQU	20

A DMA mechanism allows the 6801 master to scan the DCBs for pending work. The 6801 master writes completion messages and data to the DCBs or data areas as indicated in DCB messages. The Z80 either deposits commands into the DCBs, or inspects the DCBs for the completion status of previously issued commands.

A single data structure (PCB) allows the Z80 to communicate with the 6801 master.

3.9 Functional Overview - Z80 and 6801 Master

The following table provides a functional overview of the Z80 and 6801 master. The three pages following the table provide further details.

<u>Layer</u>	<u>Responsibilities</u>
Z80	Administer PCB, DCB, and data blocks Signal 6801_Master_App Scheduling and prioritizing
6801_Master_App	Scan DCBs (Events from Z80) Post I/O to 6801Mac Send control signals Collect signals Interpret PCB and DCBs
6801_Master_Mac	Control network Write/read data to/from Z80. MEM based on NIM_BLK

Z80

Inputs

1. Processor_Control_Block (to function #3)
2. Device_Control_Block (to function #3)
3. Memory_Blocks (to function #1)

Functions

1. To manage data for PCB, DCBs and Memory Blocks.
2. To send signals to the 6801_MASTER_APP.
 - a. Processor Commands
 - b. Device Commands
3. To receive signals from the 6801_MASTER_APP.
 - a. Process_Status
 - b. Device_Status
4. To administer the priority of scheduling devices by regulating the frequency within which the Z80_MASTER posts commands to the applicable DEVICE_CONTROL_BLOCK_COMMAND.

Outputs

1. PCB (from functions #4, 2)
2. DCB (from functions #4, 2)
3. MEM BLOCKS (from function #4)

Note: Z80_MASTER must allocate the MAX message length buffer for the sending/receiving node's message.

6801 Master App

Inputs

1. PCB (to functions #2, 3)
2. DCBs (to function #1, 3)
3. NIM_BLKs (to function #4)

Functions

1. To scan the DCBs for changes of state to the DCB(i).
DEVICE_COMMAND field.
2. To scan the PCB.
3. To interpret the scanned information.
4. To receive I/O completion signals from the MAC.
(Deposited in M_SIG).
5. To post I/O requests to the 6801_MASTER_MAC.
6. To post processor status information to the Z80 MASTER.
7. To post DEVICE_STATUS information to the Z80_MASTER.

Outputs

1. PCB (from function #6)
2. DCB (from function #7)
3. NIM_BLK (from function #4)

6801 Master Mac

Inputs

1. NET_IN MESSAGES (to functions #1, 3)
2. NIM_BLK (to functions #1, 2, 5)

Functions

1. To sequence the I/O of the network.
2. To send messages to devices.
3. To receive messages from devices.
4. To signal status information to the 6801_MASTER_APP.
5. To execute 6801_MASTER_APP signals.

Outputs

1. NET_OUT MESSAGES (to functions #1, 2)
2. NIM_BLK (to functions #1, 4)

4. OPERATING SYSTEM

4.1 EOS (Elementary Operating System)

This section provides information to allow designers to write programs that operate in an Adam/EOS environment. It describes the organization of the Elementary Operating System (EOS) including file management and executive calls.

The Elementary Operating System is a collection of service routines that provide input/output facilities to peripheral devices. Programs accessing these devices need not be concerned with the physical characteristics of the devices, because EOS logically resides between the physical devices and application programs. EOS shields application programs from the details of AdamNet.

Entries to EOS are defined in Subsection 4.1.7. Application programs should use only these entry points. Access to EOS in any other manner is dangerous and may cause program malfunction. EOS error codes are listed in Subsection 4.1.8.

FIGURE 3-4: EOS MEMORY MAP

FILE CONTROL BLOCK HEADERS	D390H
FCB BUFFERS (3X1KB)	D400H
EOS CODE	E000H
ADAMNET DEVICE DRIVERS	F400H
EOS DATA TABLES	FBFFH
EOS JUMP TABLES	FC30H
GLOBAL RAM AREA	FD50H
PROCESSOR CONTROL BLOCK	FEC0H
DEVICE CONTROL BLOCK	FEC4H
DMA RESERVED BYTE	FFFFH

4.1.1 EOS Overwrite Addresses

Some applications may not require all of the routines provided by EOS. To accommodate this situation, EOS has three defined starting locations. Applications should always access the routines from the defined jump table locations.

Location 0D390H is the lowest EOS starting address. File manager software is located in this part of EOS. If the application program uses file manager software, the application should not overwrite 0D390H or above.

Location 0E000H. If the application does not use the file manager software, it can overwrite EOS up to 0DFFFH. Routines that access the lower level network device drivers, and the device drivers for the VDP, controllers and sound generator are available.

Locations 0F400H to 0FC30H contain the lowest level device drivers for AdamNet. The application can extend up to 0F3FFH if it is using OS_7 or its own drivers for the VDP, controllers and sound generator.

4.1.2 EOS Files

The file structure takes advantage of the sequential design of the data pack. (For more information on tapes and tape formats, see Chapter 3, Section 5.) A file directory keeps track of the location of files on tape, and other pertinent information such as size, creation date, and protection attributes. Some programs, such as super games, do not require directories.

Data is stored on tape in blocks of 1K (1024 bytes). An EOS file occupies a number of contiguous blocks, allocated upon file creation. EOS files can be any number of blocks but; are limited by the physical storage space available.

Block 0 is reserved for a cold start loader. Block 1 and up, depending on the directory size, contain the directory.

The EOS file manager accesses and controls a file through a File Control Block (FCB) maintained in RAM. The FCB contains static and dynamic information about the file. The FCB is created when a file is opened and destroyed when the file is closed. Application programs are limited to two FCBs at any one time. Each FCB is 36 bytes long. A data buffer, 1024 bytes long, is associated with each FCB.

The Directory

The directory contains two types of records: Volume and File Records. The first 26 bytes of the first block in the directory is the Volume Record. The Volume Record is followed by a number of File Records, also 26 bytes in length. The 13th byte of the Volume Record determines the size of the directory. Up to 127 blocks may be allocated for the directory, allowing a maximum of 4953 file entries, and 39 directory entries per 1K block.

Size (bytes)	(12)	(1)	(4)	(4)	(2)	(3)
	VOL_NAME	DIRECTORY SIZE	DIR_CHECK	VOL_SIZE	reserved	CREATION DATE

Volume Record

Size (bytes)	(12)	(1)	(4)	(2)	(2)	(2)	(3)
	DIR_NAME	DIR ATTRIB	DIR_START BLOCK	DIR_MAX LENGTH	DIR_USED LENGTH	DIR_LAST COUNT	CREATION DATE

File Record

<u>Name</u>	<u>Length</u>	<u>Explanation</u>						
VOL_NAME	12 bytes	Logical Volume Name						
DIRECTORY SIZE	1 byte							
VOL_ATTR	Bit 7	Delete protection if set to 1						
VOL_DIRSIZE	Bits 6-0	Directory size in blocks						
DIR_CHECK	4 bytes	A unique code that indicates the presence of a directory.						
VOL_SIZE	4 bytes	Total number of blocks allocated						
CREATION DATE	3 bytes							
		<table> <tr> <td>(1)</td><td>(1)</td><td>(1)</td></tr> <tr> <td>VOL_YEAR</td><td>VOL_MONTH</td><td>VOL_DAY</td></tr> </table>	(1)	(1)	(1)	VOL_YEAR	VOL_MONTH	VOL_DAY
(1)	(1)	(1)						
VOL_YEAR	VOL_MONTH	VOL_DAY						
DIR_NAME	12 bytes	file name. 12th byte denotes file type (A, a, H or h). Terminated by ETX (03H). (See 4.1.3)						

DIR_ATTRIB

1 byte

File attribute byte

Bits:

7	6	5	4	3	2	1	0
p	w	r	u	s	a	e	f

p: permanently protected bit
w: write protected
r: read protected
u: user file
s: system file
a: file has been deleted
e: execute protect
 (0 = execute
 (1 = no execute)
f: not a file

A typical user-defined file would have a DIR-ATTRIB of 10H. An executable file, which is loaded and run from 100H, has a DIR_ATTRIB of 0C8H.

DIR_START_BLOCK

4 bytes

Starting block number of the file

DIR_MAX_LENGTH

2 bytes

File size in blocks

DIR_USED_LENGTH

2 bytes

Number of blocks used, including any partially used blocks

DIR_LAST_COUNT

2 bytes

Number of bytes in the last block.
(0 - 400)

CREATION DATE

3 bytes

DIR_YR	DIR_MNTH	DIR_DAY
--------	----------	---------

File Control Block (FCB) Organization

# bytes			
12	FCB_NAME	Up to eleven characters, free format	
1	FCB_ATTR	Same as attribute byte of File Record	
4	FCB_START_BLOCK	File starting block number on tape	
2	FCB_MAX_LENGTH	Total number of blocks allocated	
2	FCB_USED_LENGTH	Number of blocks used within the file	
2	FCB_LAST_COUNT	Number of bytes in last block of the file	
1	FCB_DEVICE	Device containing the file. See below.	
1	FCB_MODE	File open modes. See below.	
4	FCB_BLOCK	Block number currently in FCB_BUFFER	
4	FCB_LAST_BLOCK	Last block number of the file	
2	FCB_POINTER	FCB_BUFFER pointer	
1	FCB_LENGTH	Data block size of the current FCB_DEVICE	
1024	FCB_BUFFER	1K buffer allocated for each file currently opened. Matches the block size on the digital data pack. Controlled by the EOS file manager to transfer data between the user program and mass storage devices.	

FCB_DEVICE

A unique number assigned to all devices (present and future):

- 00H - Master
- 01H - Keyboard
- 02H - Printer
- 03H - Reserved
- 04H - Floppy Disk Drive - 1
- 05H - Floppy Disk Drive - 2
- 06H - Reserved
- 07H - Reserved
- 08H - Data Pack Drive - 1
- 18H - Data Pack Drive - 2
- 09H - Reserved
- 0AH - Reserved
- 0BH - Reserved
- 0CH - Reserved
- 0DH - Parallel Interface Module

OEH - RS-232C Interface Module
OFH - Gateway

4.1.3 File Types and Headers

The 12th character of DIR_NAME indicates the file type. Valid file types are A, a, h or H. The lower case file types indicate backup versions of a file. These files have the user file attribute bit set. The first three bytes of an "H" file define the length of the header and the application code. Following these bytes are the header and then ASCII information. Refer to Subsection 6.2 for an example of an "H" file.

The application code defines the format of the header. The following application codes have been assigned:

- 1 SmartWRITER
- 2 SmartBASIC
- 16 Electronic FlashCard Maker

"A" files have the user bit set, but do not contain headers. ASCII information begins in the first byte of the file.

4.1.4 EOS Executive Calls

This subsection summarizes EOS executive subroutines that can be called from application programs. The executive calls fall into three categories: system operations, simple device I/O and mass storage file I/O.

System Operations

<u>_EOS_START</u>	Starts EOS by going through initialization steps
<u>_HARD_INIT</u>	Initializes the system at powerup
<u>_SOFT_INIT</u>	Initializes the system anytime but powerup
<u>_HARD_RESET_NET</u>	Applies hardware reset (38H) to AdamNet
<u>_SYNC</u>	Synchronizes Z80 with Master 6801
<u>_SCAN_ACTIVE</u>	Scans devices on AdamNet and establishes the Device Control Blocks (DCB)
<u>_RELOC_PCB</u>	Relocates PCB and DCBs to different addresses after powerup if necessary
<u>_FIND_DCB</u>	Finds the DCB address for the assigned device
<u>_GET_DCB_ADDR</u>	Same as <u>_FIND_DCB</u>
<u>_GET_PCB_ADDR</u>	Finds the current PCB address of the system
<u>_REQUEST_STATUS</u>	Issues a status request command to a device

Simple Device Operations

<u>CONS_INIT</u>	Initializes the system console
<u>CONS_OUT</u>	Displays a character or performs screen control on the system console
<u>REQ_KBD_STAT</u>	Requests keyboard status
<u>REQ_PR_STAT</u>	Requests printer status
<u>RD_CH_DEV</u>	Indicates a read command to a character device
<u>RD_KBD</u>	Reads a character from the keyboard
<u>START_RD_CH_DEV</u>	Sets up a character device DCB to issue read command (concurrent operation)
<u>END_RD_CH_DEV</u>	Checks the status of character device DCB after command has been sent to read (concurrent)
<u>START_RD_KBD</u>	Starts a keyboard read command (concurrent)
<u>END_RD_KBD</u>	Checks the keyboard status (concurrent)
<u>WR_CH_DEV</u>	Initiates a write command to a character device
<u>PR_CH</u>	Prints a character on the printer
<u>PR_BUFF</u>	Prints string of ASCII characters terminated by ETX (03)
<u>START_WR_CH_DEV</u>	Sets up a character device DCB to issue write command (concurrent)
<u>END_WR_CH_DEV</u>	Checks the status of character device DCB after command has been sent to write (concurrent)
<u>START_PR_CH</u>	Starts a printer print command (concurrent)
<u>END_PR_CH</u>	Checks the printer status (concurrent)
<u>START_PR_BUFF</u>	Starts the command of printing a string of characters (concurrent)
<u>END_PR_BUFF</u>	Checks the printer status (concurrent)

Mass Storage Device Operations

File Manager Section

<u>SET_DATE</u>	Sets the current date
<u>GET_DATE</u>	Gets the current date
<u>QUERY_FILE</u>	Reads directory entry of a file
<u>SET_FILE</u>	Sets the file directory entry
<u>MAKE_FILE</u>	Creates a file in the directory
<u>OPEN_FILE</u>	Opens a file by setting up the FCB
<u>CLOSE_FILE</u>	Closes a file by marking the FCB
<u>RESET_FILE</u>	Resets the file by pointing back to the first byte
<u>READ_FILE</u>	Reads data from a file into user's buffer
<u>WRITE_FILE</u>	Writes data to a file
<u>FMGR_INIT</u>	Initializes the file manager
<u>SCAN_FOR_FILE</u>	Scans the directory block(s) for a file

Device Driver Section

<u>_RD_1_BLOCK</u>	Reads a block of data (1024 bytes) from mass storage device
<u>_WR_1_BLOCK</u>	Writes a block of data to mass storage device. I/O buffers containing data to be transferred to tape can reside anywhere in Z80 RAM.
<u>_REQ_TAPE_STAT</u>	Requests status of the data pack drive
<u>_START_RD_1_BLOCK</u>	Sends read command to read a block of data from a block device (concurrent)
<u>_END_RD_1_BLOCK</u>	Checks status after <u>_START_RD_1_BLOCK</u>
<u>_START_WR_1_BLOCK</u>	Sends write command to write a block of data to a block device (concurrent)
<u>_END_WR_1_BLOCK</u>	Checks status after <u>_END_WR_1_BLOCK</u>

4.1.5 EOS Routines Adapted from OS 7

A section of EOS contains device drivers for the video processor, sound generator and controllers. Many of these routines are functionally the same as routines in the OS_7 ROM. The inputs and outputs for the EOS version of these routines is not necessarily the same as those for equivalent routines in OS_7. Entry points are defined in Subsection 4.1.7. The file A_uOS_00 in the EOS Source Code specifies parameter passing.

Routines for the Video Processor

WRITE_VRAM	READ_VRAM
WRITE_REGISTER	READ_REGISTER
FILL_VRAM	INIT_TABLE
PUT_VRAM	GET_VRAM
CALC_OFFSET	PX_TO_PTRN_POS
LOAD_ASCII	PUT_ASCII
WR_SPR_ATTRIBUTE	

Routines for the Controllers

DECODER	POLLER
SPINNER	

Routines for the Sound Processor

DECLSN	DECMSN
MSNTOLSN	ADD8TO16
SOUND_INIT	TURN_OFF_SOUND
PLAY_IT	SOUNDS
EFFECT_OVER	

Adam Routines for OS_7 Access

SWITCH_MEM	PORT_COLLECTION
------------	-----------------

4.1.6 Initializing EOS

No initialization of EOS is necessary if an application program boots from disk or data pack. If a program boots from the cartridge slot or a connector, EOS must be loaded from ROM to its executable location, according to the following procedure. This procedure must be executed from address range 8000H through 0DFFFH in intrinsic RAM.

Step 1: Select the SmartWRITER option in lower memory.

out 7FH,00H

Step 2: Strobe the EOS_ENABLE line by writing the value 02H to port 3FH.

```
out 3FH,02H
```

Step 3 Copy EOS from location 6000H to location 0E000H. Do not overwrite the DCBs.

```
LD HL,6000H
LD DE,0E000H
LD BC,0FEC0H - 0E000H
LDIR
```

Step 4: Deselect EOS ROM. EOS ROM should be deselected if the SmartWRITER ROMS will be accessed by the application program. LOAD_ASCII is an example of an EOS routine which accesses the EOS ROM.

```
out 3FH,0
```

Step 5: Initialize EOS tables. All RAM should be cleared to 0. See Subsection 4.1.7 for the equate values.

```
LD BC,CLEAR_RAM_SIZE
LD DE,CLEAR_RAM_START+1
LD HL,CLEAR_RAM_START
XDR A
LD [HL],A
LDIR
```

Step 6: Initialize I/O ports. EOS collects port values from the OS_7 ROM. EOS routines use these ports when they access the video processor, controllers and sound generator.

```
CALL PORT_COLLECTION
```

Step 7: Initialize AdamNet. _HARD_INIT performs the 6801/Z80 synchronization, performs a roll call poll on the network, and establishes the DCBs.

```
CALL _HARD_INIT
```


4.1.7 EOS Entry Points

ADD816	EQU 0FD4DH :P	MEM_CNFG0F	EQU 0FC26H :A
BLK_STRT_PTR	EQU 0FDDCH :D	MEM_SWITCH_PORT	EQU 0FC27H :A
BLOCKS_REQ	EQU 0FE0CH :D	MOD_FILE_COUNT	EQU 0FDD5H :D
BUF_END	EQU 0FE0AH :D	MSNTOLSN	EQU 0FD4AH :P
BUF_START	EQU 0FE08H :D	NET_RESET_PORT	EQU 0FC28H :A
BYTES_REQ	EQU 0FE02H :D	NEW_HOLE_SIZE	EQU 0FE1AH :D
BYTES_TO_GO	EQU 0FE04H :D	NEW_HOLE_START	EQU 0FE16H :D
CALC_OFFSET	EQU 0FD32H :P	NUM_COLUMNS	EQU 0FEA0H :D
CLEAR_RAM_SIZE	EQU 0Q147H :A	NUM_LINES	EQU 0FE9FH :D
CLEAR_RAM_START	EQU 0FD60H :D	JLDCHAR	EQU 0FE79H :D
COLORTABLE	EQU 0FD6CH :D	PATRRNGENTBL	EQU 0FD6AH :D
CONTROLLER_0_PD	EQU 0FC2BH :A	PATRRNAMETBL	EQU 0FD68H :D
CONTROLLER_1_PD	EQU 0FC2CH :A	PCB	EQU 0FEC0H :A
CURRENT_DEV	EQU 0FD6FH :D	PERSONAL_DEBOUN	EQU 0FE5AH :D
CURRENT_PCB	EQU 0FD70H :D	PLAY_IT	EQU 0FD56H :P
CURSOR	EQU 0FEA5H :D	POLLER	EQU 0FD3EH :P
CUR_BANK	EQU 0FD6EH :D	PORT_COLLECTION	EQU 0FD11H :P
DCB_IMAGE	EQU 0FD8BH :D	PORT_TABLE	EQU 0FC27H :A
DECLSN	EQU 0FD44H :P	PRINT_BUFFER	EQU 0FD76H :D
DECMSN	EQU 0FD47H :P	PTRN_NAME_TBL	EQU 0FEA3H :D
DEFAULT_BT_DEV	EQU 0FD6FH :D	PTR_TO_LST_OF_S	EQU 0FE6EH :D
DEVICE_ID	EQU 0FD72H :D	PTR_TO_S_ON_0	EQU 0FE70H :D
DIR_BLOCK_NO	EQU 0FDD9H :D	PTR_TO_S_ON_1	EQU 0FE72H :D
EFFECT_OVER	EQU 0FD5CH :P	PTR_TO_S_ON_2	EQU 0FE74H :D
EOS_DAY	EQU 0FDE2H :D	PTR_TO_S_ON_3	EQU 0FE76H :D
EOS_MONTH	EQU 0FDE1H :D	PUT_ASCII	EQU 0FD17H :P
EOS_STACK	EQU 0FE58H :D	PUT_VRAM	EQU 0FD2CH :P
EOS_YEAR	EQU 0FDE0H :D	PX_TO_PTRN_POS	EQU 0FD35H :P
PCB_BUFFER	EQU 0FDBAH :D	QUERY_BUFFER	EQU 0FDA0H :D
FCB_DATA_ADDR	EQU 0FDFFH :D	READ_REGISTER	EQU 0FD23H :P
FCB_HEAD_ADDR	EQU 0FDFFH :D	READ_VRAM	EQU 0FD1CH :P
FILENAME_CMPS	EQU 0FDDBH :D	RETRY_COUNT	EQU 0FD06H :D
FILE_COUNT	EQU 0FD04H :D	REV_NUM	EQU 0FD60H :D
FILE_NAME_ADDR	EQU 0FD73H :D	SAVE_CTRL	EQU 0FE78H :D
FILE_NUMBR	EQU 0FD07H :D	SECTORS_TO_INIT	EQU 0FD86H :D
FILL_VRAM	EQU 0FD26H :P	SECTOR_NO	EQU 0FD87H :D
FMGR_DIR_ENT	EQU 0FDE3H :D	SOUNDPORT	EQU 0FC2FH :A
FNUM	EQU 0FE01H :D	SOUNDS	EQU 0FD59H :P
FOUND_AVAIL_ENT	EQU 0FDD8H :D	SOUND_INIT	EQU 0FD50H :P
GET_VRAM	EQU 0FD2FH :P	SPIN_SW0_CT	EQU 0FE58H :D
INIT_TABLE	EQU 0FD29H :P	SPIN_SW1_CT	EQU 0FE59H :D
INT_VCTR_TBL	EQU 0FBFFH :A	SPRITEATTRTBL	EQU 0FD64H :D
KEYBOARD_BUFFER	EQU 0FD75H :D	SPRITEGENTBL	EQU 0FD66H :D
LINEBUFFER	EQU 0FE7EH :D	START_BLOCK	EQU 0FE12H :D
LOAD_ASCII	EQU 0FD38H :P	STROBE_RESET_PD	EQU 0FC2EH :A
MEM_CNFG00	EQU 0FC17H :A	STROBE_SET_PORT	EQU 0FC2DH :A
MEM_CNFG01	EQU 0FC18H :A	SWITCH_MEM	EQU 0FD14H :P
MEM_CNFG02	EQU 0FC19H :A	SWITCH_TABLE	EQU 0FC17H :A
MEM_CNFG03	EQU 0FC1AH :A	TEMP_STACK	EQU 0FE6EH :D
MEM_CNFG04	EQU 0FC1BH :A	TURN_OFF_SOUND	EQU 0FD53H :P
MEM_CNFG05	EQU 0FC1CH :A	UPDATE_SPINNER	EQU 0FD41H :P
MEM_CNFG06	EQU 0FC1DH :A	UPPER_LEFT	EQU 0FEA1H :D
MEM_CNFG07	EQU 0FC1EH :A	USER_BUF	EQU 0FE06H :D
MEM_CNFG08	EQU 0FC1FH :A	USER_NAME	EQU 0FE10H :D
MEM_CNFG09	EQU 0FC20H :A	VDP_CTRL_PORT	EQU 0FC29H :A
MEM_CNFG0A	EQU 0FC21H :A	VDP_DATA_PORT	EQU 0FC2AH :A
MEM_CNFG0B	EQU 0FC22H :A	VDP_MODE_WORD	EQU 0FD61H :D
MEM_CNFG0C	EQU 0FC23H :A	VDP_STATUS_BYTE	EQU 0FD63H :D
MEM_CNFG0D	EQU 0FC24H :A	VECTOR_08H	EQU 0FBFFH :A
MEM_CNFG0E	EQU 0FC25H :A	VECTOR_10H	EQU 0FC02H :A
		VECTOR_18H	EQU 0FC05H :A
		VECTOR_20H	EQU 0FC08H :A
		VECTOR_28H	EQU 0FC0BH :A

4.1.7 EOS Entry Points

VECTOR_30H	EQU 0FC0EH :A	_REQ_TAPE_STAT	EQU 0FC87H :P
VECTOR_38H	EQU 0FC11H :A	_RESET_FILE	EQU 0FCC6H :P
VECTOR_66H	EQU 0FC14H :A	_SCAN_ACTIVE	EQU 0FC8AH :P
VOL_BLK_SZ	EQU 0FDDCH :D	_SCAN_FOR_FILE	EQU 0FCFCH :P
VRAM_ADDR_TABLE	EQU 0FD64H :D	_SET_DATE	EQU 0FCD8H :P
WRITE_REGISTER	EQU 0FD20H :P	_SET_FILE	EQU 0FCCFH :P
WRITE_VRAM	EQU 0FD1AH :P	_SOFT_INIT	EQU 0FC8DH :P
WR_SPR_ATTRIBUT	EQU 0FD3BH :P	_SOFT_RES_DEV	EQU 0FC90H :P
X_MAX	EQU 0FE7BH :D	_SOFT_RES_KBD	EQU 0FC93H :P
X_MIN	EQU 0FE7AH :D	_SOFT_RES_PR	EQU 0FC96H :P
Y_MAX	EQU 0FE7DH :D	_SOFT_RES_TAPE	EQU 0FC99H :P
Y_MIN	EQU 0FE7CH :D	_START_PR_BUFF	EQU 0FC9CH :P
_CHECK_FCB	EQU 0FCF0H :P	_START_PR_CH	EQU 0FC9FH :P
_CLOSE_FILE	EQU 0FCC3H :P	_START_RD_1_BLD	EQU 0FCA2H :P
_CONS_DISP	EQU 0FC33H :P	_START_RD_CH_DE	EQU 0FCASH :P
_CONS_INIT	EQU 0FC36H :P	_START_RD_KBD	EQU 0FCABH :P
_CONS_OUT	EQU 0FC39H :P	_START_WR_1_BLD	EQU 0FCABH :P
_CV_A	EQU 0FD0EH :P	_START_WR_CH_DE	EQU 0FCAEH :P
_DELETE_FILE	EQU 0FCE1H :P	_SYNC	EQU 0FCB1H :P
_DLY_AFT_HRD_RE	EQU 0FC3CH :P	_TRIM_FILE	EQU 0FCEDH :P
_END_PR_BUFF	EQU 0FC3FH :P	_WRITE_BLOCK	EQU 0FCF6H :P
_END_PR_CH	EQU 0FC42H :P	_WRITE_FILE	EQU 0FCD5H :P
_END_RD_1_BLOCK	EQU 0FC45H :P	_WR_1_BLOCK	EQU 0FCB4H :P
_END_RD_CH_DEV	EQU 0FC48H :P	_WR_CH_DEV	EQU 0FCB7H :P
_END_RD_KBD	EQU 0FC4BH :P		
_END_WR_1_BLOCK	EQU 0FC4EH :P		
_END_WR_CH_DEV	EQU 0FC51H :P		
_EOS_1	EQU 0FD05H :P		
_EOS_2	EQU 0FD08H :P		
_EOS_3	EQU 0FD0BH :P		
_EOS_START	EQU 0FC30H :P		
_FILE_QUERY	EQU 0FCFFH :P		
_FIND_DCB	EQU 0FC54H :P		
_FMGR_INIT	EQU 0FCBAH :P		
_GET_DATE	EQU 0FCDBH :P		
_GET_DCB_ADDR	EQU 0FC57H :P		
_GET_PCB_ADDR	EQU 0FC5AH :P		
_GOTO_WP	EQU 0FCE7H :P		
_HARD_INIT	EQU 0FC5DH :P		
_HARD_RESET_NET	EQU 0FC60H :P		
_INIT_TAPE_DIR	EQU 0FCBDH :P		
_MAKE_FILE	EQU 0FCC9H :P		
_MODE_CHECK	EQU 0FCF9H :P		
_OPEN_FILE	EQU 0FCC0H :P		
_POSIT_FILE	EQU 0FD02H :P		
_PR_BUFF	EQU 0FC63H :P		
_PR_CH	EQU 0FC66H :P		
_QUERY_FILE	EQU 0FCCC :P		
_RD_1_BLOCK	EQU 0FC69H :P		
_RD_DEV_DEP_STA	EQU 0FCE4H :P		
_RD_KBD	EQU 0FC6CH :P		
_RD_KBD_RET_COD	EQU 0FC6FH :P		
_RD_PR_RET_CODE	EQU 0FC72H :P		
_RD_RET_CODE	EQU 0FC75H :P		
_RD_TAPE_RET_CO	EQU 0FC78H :P		
_READ_BLOCK	EQU 0FCF3H :P		
_READ_EOS	EQU 0FCEAH :P		
_READ_FILE	EQU 0FCD2H :P		
_RELOC_PCB	EQU 0FC7BH :P		
_RENAME_FILE	EQU 0FCDEH :P		
_REQUEST_STATUS	EQU 0FC7EH :P		
_REQ_KBD_STAT	EQU 0FC81H :P		
_REQ_PR_STAT	EQU 0FC84H :P		

4.1.8 EOS Error Codes

DCB_NOT_FOUND	EQU	1
DCB_BUSY	EQU	2
DCB_IDLE_ERR	EQU	3
NO_DATE_ERR	EQU	4
NO_FILE_ERR	EQU	5
FILE_EXISTS_ERR	EQU	6
NO_FCB_ERR	EQU	7
MATCH_ERR	EQU	8
BAD_FNUM_ERR	EQU	9
EOF_ERR	EQU	10
TOO_BIG_ERR	EQU	11
FULL_DIR_ERR	EQU	12
FULL_TAPE_ERR	EQU	13
FILE_NM_ERR	EQU	14
RENAME_ERR	EQU	15
DELETE_ERR	EQU	16
RANGE_ERR	EQU	17
CANT_SYNC1	EQU	18
CANT_SYNC2	EQU	19
PRT_ERR	EQU	20
RQ_TP_STAT_ERR	EQU	21
DEVICE_DEPD_ERR	EQU	22
PROG_NON_EXIST	EQU	23
NO_DIR_ERR	EQU	24

4.2 OS 7

4.2.1 Introduction

This subsection presents an overview of the ColecoVision Operating System, referred to as the OS or OS_7. In contrast to the typical definition of an operating system as a run-time executive, the ColecoVision OS is a run-time user's library that provides access to modules which control events related to graphics, sounds, timing, etc.

Appendix 3 contains the detail sections of the ColecoVision Programmer's Manual, which document each module. Included are the calling sequence, input/output parameters, side effects, and calls to other OS routines. The documentation assumes that the programmer is familiar with the Z80 instruction set.

The ColecoVision OS provides power-up procedures and system-defined entry points for the user. It handles input/output operations and housekeeping functions. The OS provides the displayable ASCII character set and vectors into the cartridge memory space that correspond to the Z80 hardware restart and interrupt vectors.

The OS software can be divided functionally as follows:

- Graphics Generation
- Sound Generation
- Interrupt Handling and Write Deferral
- Timing
- Controller Interface
- Boot-up
- Miscellaneous Utilities
- Defined Reference Locations

4.2.2 Graphics Generation Software

Software in this area is divided into the chip driver level, the table level and the object level. First, there are chip drivers for the TMS 9928 level. Software to initialize and manipulate tables belongs to the table level. Video graphics are generated by objects on the object level. Each object has its own definition of tables, frames and display locations called out by the user.

4.2.3 Sound Generation Software

Sound generation software produces tones and music by table "look-up." The software also has provisions to produce special effects. A prioritization scheme allows important

sounds to overlay less important background sounds without destroying their continuity.

4.2.4 Interrupt Handling and Write Deferral Software

When the OS is accessing the VDP register or VRAM, protection may be needed when a VDP interrupt occurs. Interrupt deferral routines handle this situation when top-level graphics software is in use. Bulletin No. 10 in Appendix D of the ColecoVision Programmer's Manual lists additional interrupt deferral software to fix the problem at low-level VDP access.

4.2.5 Timing Software

In a real-time application, timing is essential to the system operation. The OS timing software manages the software timers allocated by the user. It allows the user to start the timer, update the timer, check if it is timed out and then relinquish the timer. The number of software timers that can be supported depends on available cartridge RAM.

4.2.6 Controller Interface

The controller interface has several features:

The process of scanning, debouncing and decoding controller inputs is automatic upon invoking the OS routines.

The software only debounces and decodes those inputs that the user wishes to access.

The user has the option of bypassing automatic scanning and decoding and accessing the raw controller data, if necessary.

4.2.7 Boot-Up Software

The OS performs certain initialization tasks, such as turning off the sound chip, initializing buffers and flags, and display of the standard logo screen. If no game cartridge is present, it warns the user to turn off the system before attempting to insert a cartridge or expansion module.

If a cartridge is present, the OS reads the cartridge title from a predefined location and displays it along with copyright information. This screen is displayed for a short time before the OS relinquishes control to the cartridge software.

4.2.8 Miscellaneous Utilities

This software includes some low-level utilities, evolved in conjunction with the graphics and sound packages. It inclu-

des a nibble arithmetic package and a routine that displays a standard game-option screen.

4.2.9 Defined Reference Locations


OS_7 has a number of system-defined reference locations in the areas of cartridge RAM, OS ROM and Cartridge ROM. The user-accessible locations are listed in the file, OS_SYMBOLS, Rev. 2 (Appendix F of the ColecoVision Programmer's Manual). It is IMPORTANT for the user to call the OS subroutines through those authorized entry points (Jump Table). The user also must be aware of the limitation of using cartridge RAM as a scratch pad due to the predefined OS data areas and stack memory. Locations at the beginning of the cartridge program may be accessed for pointers to the tables and buffers in CRAM. Also in this area, restart and interrupt vectors are defined for the user. Section X of the ColecoVision Programmers Manual lists all the system defined locations in all memory areas.

5. TAPE FORMAT AND OTHER TAPE CONSIDERATIONS


There are two types of tape format for ADAM data packs. Type GW tapes have block 0 at the end. Type HE tapes have block 0 in the middle. An example of a type GW is The Buck Rogers™ Plaent of Zoom™ Super Game. Both SmartBASIC and the blank data pack are examples of type HE tapes.

The capacity of the tape is 256K. Blocks are defined as 1K in length. There are two tracks, 128 blocks per track. Block numbers refer to the block of data on a data pack referenced by application software. The following illustration shows physical block positions.

FORMAT GW (Block 0 at the end)



Format HE (Block 0 in the middle)




Considerations in Choosing Tape Format

Type GW tapes do not contain a directory. Type GW tapes cannot be readily copied, so users are not able to easily copy one GW tape to another GW tape.

Type HE tapes are compatible with other type HE tapes. If a program needs to store information on a separate data pack, access or be accessed by other software, then a type HE tape is suggested.

6. SmartWRITER

6.1 Memory Map



6.2

SmartWRITER-Compatible Files

Files must meet certain criteria to be compatible with SmartWRITER. SmartWRITER files have the user file attribute bit set, and the last character of the file name is H. SmartWRITER files start with a header and ASCII information begins after the header. The first two bytes of the file define the length of the header. The third byte contains the application code (1 for SmartWRITER). The format of the header is determined by the application code. Backup versions of SmartWRITER files have a lower-case "h" as the file type.

An example of a SmartWRITER file follows:

BYTE DESCRIPTION

0	HEADER_SIZE_LOW (=256)
1	HEADER_SIZE_HIGH (=0)
2	FILE_TYPE_CODE (=1)
3	TOP_MARGIN
4	BOTTOM_MARGIN
5	LEFT_MARGIN
6	RIGHT_MARGIN
7	LINE_SPACING
8	TAB_ARRAY (1) [0 = NO MRG, 1 = MRG]
89	TAB_ARRAY (80) [0 = NO MRG, 1 = MRG]
90	UNUSED
258	UNUSED
259	FIRST ASCII DATA BYTE
n	ASCII DATA


7. SmartBASIC

SmartBASIC is generally source-code compatible with Applesoft BASIC. PEEKS and POKES, and other machine-dependent features of Applesoft BASIC are different in SmartBASIC. SmartBASIC graphics feature four modes:

- Text mode - 24 lines of 31 characters
- low resolution graphics - 40 x 40, with four lines of text
- high resolution graphics - 256 x 160 with four lines of text
- Pure high resolution graphics - 256 x 192

7.1


Memory Map



8. SUPER GAMES AND OTHER PROGRAMS USING OS7

Refer to Chapter 5, Section 2 for a detailed explanation of the Buck Rogers™ Planet of Zoom™ Super Game. The Buck Rogers game serves as an example for developers of super games.

8.1 MEMORY MAP



* ADAM EOS starts at D390. In this example of a super game, only the AdamNet device drivers in EOS are needed. Refer to Chapter 3, Subsection 4.1.1, EOS Overwrite Addresses.

Address 0000 through 1FFF

OS_7 ROM is available for program use and requires 8K.

Address F400 through FFFF

EOS is used to access peripherals and files, and requires 3K.

Address 2000 through F3FF

The remaining 53K of Z80 RAM is available for program and data storage. OS_7 uses RAM from 7000H through 73FFH.

Address 0000 through 3FFF VDP RAM

Unused portions of the 16K VDP RAM may be used as temporary storage. VDP RAM may not be loaded directly from tape, but must be read into intrinsic RAM, then transferred using one of the VDP access routines.

9. ROM-BASED CARTRIDGE PROGRAMS

9.1 Memory Map

