


Disassembly

1. Turn unit over so that bottom is in an upright position.
2. Remove eight bottom screws.
3. Turn unit back over so that top is once again in the upright position.
4. To remove top housing, carefully pull out and up in front, then do the same for the back, do this back and forth, firmly, until the top housing pops off. At this point do not tamper with the front housing. There is never a need for it to be removed.
5. Remove reset switch and on/off switch caps.
6. Unsolder and unscrew top RF shield and ground strap and remove.
7. Remove two screws from printed circuit board and repair.

Assembly

1. Replace printed circuit board and replace two screws.
2. Replace ground strap and top RF shield with screws and solder.
3. Replace reset switch and on/off switch caps. Double check, at this point, to make sure the reset switch is in place.
4. Replace top housing.
5. Turn unit over and reset eight bottom screws.
6. Turn back over to the original upright position and test your Coleco-Vision.



ColecoVision Exploded View