

ACCESSING YOUR DISK DRIVE

The procedure to access your disk drive may vary from program to program. In some cases, access is achieved by use of the ADAM™ smart keys; in others, directives are supplied through the User's Instruction Guide. Please store this handy reference card in a place where you can easily refer to it when necessary. (Sample access procedures follow.)

In SmartBASIC™

Disk Drive #1 = d5

Disk Drive #2 = d6

In SmartLOGO™

Disk Drive #1 = d4

Disk Drive #2 = d5

In Word Processing

Disk Drive #1 = c

(Disk Drive #2 is not accessible)

In most other
Coleco Programs

Disk Drive #1 = c

Disk Drive #2 = d



ADAM™, SmartBASIC™ and SmartLOGO™ are trademarks of Coleco Industries, Inc. Amsterdam, New York 12010.

© 1984 Coleco Industries, Inc. All Rights Reserved.

Printed in U.S.A.