B.A.S.I.C SI1A/B Cable pinout

This is also EVE SP-1 compatible

1	-	2	3	4	5
	6	7	8	9	10
*	-	*	*	*	*
	/	/	/	/	/
*	7	*	*	*	*

====== Circuit Board

RS232 Connector

				DB9	DB25
1	=	Clear to Send	(CTS)	8	5
2	=	Receive Data	(RXD)	2	3
3	=	Request to Send	(RTS)	7	4
4	=	Data Terminal Ready	(DTR)	4	20
5	=	Transmit Data	(TXD)	3	2
6	=	Carrier Detect	(DCD)	1	8
7	=	Not Used			
8	=	Not Used			
9	=	Signal Ground	(GND)	5	7
10	=	Not Used			