

## LIMITED WARRANTY

Coleco warrants to the original consumer purchaser of its COLECOVISION™ ROLLER CONTROLLER in the United States of America that the product will be free of defects in material or workmanship for 90 days from the date of purchase under normal in-house use.

Coleco's sole and exclusive liability for defects in material and workmanship shall be limited to repair or replacement at its authorized Coleco Service Station. This warranty does not obligate Coleco to bear the cost of transportation charges in connection with the repair or replacement of defective parts.

This warranty is invalid if the damage or defect is caused by accident, act of God, consumer abuse, unauthorized alteration or repair, vandalism, or misuse.

Any implied warranties arising out of the sale of the COLECOVISION™ ROLLER CONTROLLER including the implied warranties of merchantability and fitness for a particular purpose are limited to the above 90 day period. Coleco shall in no event be liable for incidental, consequential, contingent or any other damages.

This warranty gives you specific legal rights, and you may have other rights which vary from State to State. Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

### SERVICE POLICY

Please read the Owner's Manual carefully before using the product. If your ROLLER CONTROLLER fails to operate properly, please refer to the trouble-shooting checklist in the Owner's Manual. If you cannot correct the malfunction after consulting the trouble-shooting checklist, please call Customer Service on Coleco's toll-free service hotline: **1-800-842-1225 nationwide. This service is in operation from 8:00 a.m. to 5:00 p.m. Eastern Standard Time, Monday through Friday.**

If Customer Service advises you to return your ROLLER CONTROLLER, please return it postage prepaid and insured, with your name, address, proof of the date of purchase, and a brief description of the problem to the Service Station you have been directed to return it to by the toll-free service information. If your unit is found to be factory defective during the first 90 days, it will be repaired or replaced at no cost to you. If the unit is found to have been consumer damaged or abused and therefore not covered by the warranty, then you will be advised, in advance, of repair costs.

If your game requires service after expiration of the 90 day Limited Warranty period, please call Coleco's toll-free service hotline for instructions on how to proceed: 1-800-842-1225 nationwide.

# COLECO VISION™

## ROLLER CONTROLLER

Exciting High-Speed Action on Your  
ColecoVision™ Game System!

Package, Program and Audiovisual © 1983 Coleco Industries, Inc. Amsterdam, New York 12010

ColecoVision™ is a trademark of Coleco Industries, Inc.

### CONSUMERS PLEASE NOTE!

Please read the Owner's Manual carefully before using this product. If a malfunction occurs, please refer to the Troubleshooting Checklist. If you cannot correct the malfunction, please call Customer Service, Toll-Free nationwide:

**1-800-842-1225**

**PLEASE RETAIN THIS GUIDE  
AND ALL LITERATURE FOR FUTURE REFERENCE**

## COLECO

COLECO INDUSTRIES INC., AMSTERDAM, NEW YORK 12010

## OWNERS MANUAL


Guide No. 91950

MODEL NO. 2492

# COLECO VISION™

## ROLLER CONTROLLER

Exciting High-Speed Action on Your  
ColecoVision™ Game System!



For Ages 8 to Adult

## COLECO

COLECO INDUSTRIES INC., AMSTERDAM, NEW YORK 12010

© 1983, Coleco Industries, Inc.

Printed in U.S.A.




## CONSUMERS PLEASE NOTE!

Please read the Owner's Manual carefully before using this product. If a malfunction occurs, please refer to the Troubleshooting Checklist. If you cannot correct the malfunction, please call Customer Service, Toll-Free nationwide:

1-800-842-1225

THIS PRODUCT SHOULD BE ASSEMBLED ONLY BY AN ADULT.

## HOOKING UP YOUR ROLLER CONTROLLER



1. Unplug and remove the Hand Controllers from the ColecoVision™ Console unit.
2. Plug a Hand Controller into the socket inside a Hand Controller Well of the Roller Controller.
3. Wind the Hand Controller Cord neatly inside the Well, then slide the bottom of the Hand Controller into the Well. When Hand Controller is in place, push the top of the Hand Controller down until it snaps into place. Attach the other Hand Controller to the Roller Controller in the same manner. The Hand Controller jacks will fit only one way — **DO NOT FORCE** them into the controller sockets.
4. The WYE Connector Cable jacks have the number 1 molded on top of one jack and the number 2 molded on top of the other jack. Plug jack #1 into the rear socket, then plug jack #2 into the front socket inside the Hand Controller storage compartments of your ColecoVision™ Console unit as shown in illustration. Be sure the numbers are facing up when you are plugging in the jacks.
5. Plug the Power Adapter Plug from the Roller Controller unit into the Power Supply socket in back of your ColecoVision™ Console unit.
6. Plug the jack of the AC Power Supply unit into the back of the Power Adapter Plug as shown in illustration. Plug the AC Power Supply unit into a 110/120 volt household electrical outlet. Make sure the Power Supply is fully inserted into the electrical outlet.
7. **MODE SWITCH:** The function of the MODE SWITCH is to select between a Joystick cartridge and a cartridge designed exclusively for use with the Roller Controller. Slide the MODE SWITCH to the ROLLER Cartridge position when playing roller-game cartridges. The JOYSTICK Cartridge position can be used with most games that require use of the hand controller Joystick. Some Joystick cartridge games will be more challenging than others when played with Roller Controller. Get the "feel" of the game before you decide to use Roller Controller to play a Joystick cartridge game.

Now you are ready to begin playing your game! **BE SURE THAT THE COLECOVISION™ UNIT IS OFF BEFORE INSERTING OR REMOVING CARTRIDGE.** Refer to your GAME CARTRIDGE Instruction Guide for game play instructions.

**WARNING: ALWAYS UNPLUG THE POWER SUPPLY FROM THE 110/120 VOLT OUTLET WHEN YOU HAVE FINISHED PLAYING.**

## CARE OF YOUR GAME

- Treat your COLECOVISION™ ROLLER CONTROLLER with care.
- Before inserting or removing GAME CARTRIDGE, **always make sure that the POWER SWITCH on CONSOLE unit is turned "OFF"**.
- Always unplug the POWER SUPPLY from the 110/120 volt outlet when you have finished playing. **IMPORTANT: ONLY CONNECT THE CONSOLE POWER SUPPLY UNIT INTO A 110/120 VOLT HOUSEHOLD ELECTRICAL SERVICE, OTHERWISE SERIOUS DAMAGE MAY OCCUR TO ELECTRICAL PARTS OF THE SYSTEM.**
- Do not drop or bang ROLLER CONTROLLER, CONSOLE or HAND CONTROLLERS.
- Do not use sharp or pointed object to activate KEYPAD BUTTONS or GAME ACTION BUTTONS.
- Do not store or leave ROLLER CONTROLLER, CONSOLE and accessories where they may be subject to heat build-up.

- Keep away from moisture. Do not immerse ROLLER CONTROLLER, CONSOLE or HAND CONTROLLERS in water. Use a soft, slightly damp cloth to wipe clean.

**WARNING:** Before cleaning ROLLER CONTROLLER, CONSOLE and accessories, turn POWER SWITCH to "OFF" and disconnect the AC POWER SUPPLY unit from the 110/120 volt wall outlet.

- **Do not attempt to repair ROLLER CONTROLLER.** It does not contain any owner serviceable parts. Refer to your TROUBLESHOOTING section, if not successful refer to LIMITED WARRANTY.

## NOTICE

This game generates and uses radio frequency energy and if not installed and used properly, that is in strict accordance with the instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this game does cause interference to radio or television reception, which can be determined by turning the game off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient the TV antenna.

Relocate the game with respect to the TV.

Move the game away from the TV.

Plug the game into a different outlet so that game and TV are on different branch circuits.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful:

"How to Identify and Resolve Radio TV Interference Problems".

This booklet is available from the U.S. Government Printing Office, Washington, DC 20402, Stock No. 004-000-00345-4.

## TROUBLESHOOTING

SYMPTOM	REMEDY
■ Snow	■ Make sure that both connections for the power supply are secured in their proper ports.
■ No Hand Controller Response	■ Make sure that the switch on the Roller Controller console is in the "Joystick Cartridge" mode.
■ Roller Response Backwards	■ Make sure that the controller plugs are inserted into the correct ports on the ColecoVision Main Console.



# COLECO

The Makers of ColecoVision®

Adam™ and ColecoVision® are trademarks of Coleco Industries, Inc.

Package, Program and Audiovisual © 1983 Coleco Industries, Inc., Amsterdam, New York 12010


MODEL NO. 2492

Supplement No. 14310

## SUPPLEMENT INSTRUCTIONS FOR ROLLER CONTROLLER

### HOOKING UP YOUR ROLLER CONTROLLER TO YOUR ADAM™ FAMILY COMPUTER SYSTEM (Fig. 1)

1. **NOTE:** Before attaching your Roller Controller to the ADAM™ Computer System, unplug the printer power cord from the electrical wall outlet.
2. Unplug and remove the Hand Controllers from the memory console.
3. Plug a Hand Controller into the socket inside the Hand Controller Well of the Roller Controller. (continued on following page)



# COLECO

COLECO INDUSTRIES INC., AMSTERDAM, NEW YORK 12010

© 1983, Coleco Industries, Inc.

Printed in U.S.A.

4. Wind the Hand Controller Cord neatly inside the Well, then slide the bottom of the Hand Controller into the Well. When Hand Controller is in place, push the top of the Hand Controller down until it snaps into place. Attach the other Hand Controller to the Roller Controller in the same manner. The Hand Controller jacks will fit only one way — **DO NOT FORCE** them into the controller sockets.
5. The WYE Connector Cable jacks have the number 1 molded on top of one jack and the number 2 molded on top of the other jack. Plug the jacks into the corresponding "CONTROLLER" Sockets on the memory console, as shown in illustration. Be sure the numbers are facing up when you are plugging in jacks.
6. Remove the Printer Cable Plug from the memory console "POWER" Socket.
7. Then insert the ADAM™ Adapter into the memory console "POWER" Socket.
8. Now insert the Printer Cable Plug into the ADAM™ Adapter marked "POWER".
9. Insert the Power Adapter Plug from the Roller Controller unit into the ADAM™ Adapter marked "ACCESSORY."
10. Plug the power cord on the printer into the electrical wall outlet. Now you are ready to begin playing your game! **BE SURE THAT COMPUTER IS OFF BEFORE INSERTING OR REMOVING GAME CARTRIDGE.** Refer to your GAME CARTRIDGE Instruction Guide for game play instructions.

**NOTE:** The ADAM™ Adapter does not have to be removed from the memory console after using your Roller Controller.


## HOOKING UP YOUR ROLLER CONTROLLER TO YOUR ADAM™ FAMILY COMPUTER MODULE (Fig. 2)

1. **NOTE:** Before attaching your Roller Controller to the ADAM™ Computer Module, unplug the printer power cord from the electrical wall outlet.
2. Unplug and remove the Hand Controllers from the ColecoVision® Console unit.
3. Plug a Hand Controller into the socket inside a Hand Controller Well of the Roller Controller.
4. Wind the Hand Controller Cord neatly inside the Well, then slide the bottom of the Hand Controller into the Well. When Hand Controller is in place, push the top of the Hand Controller down until it snaps into place. Attach the other Hand Controller to the Roller Controller in the same manner. The Hand Controller jacks will fit only one way — **DO NOT FORCE** them into the controller sockets.
5. The WYE Connector Cable jacks have the number 1 molded on top of one jack and the number 2 molded on top of the other jack. Plug jack #1 into the rear socket, then plug jack #2 into the front socket inside the Hand Con-

troller storage compartments of your ColecoVision® Console unit as shown in illustration. Be sure the numbers are facing up when you are plugging in the jacks.

6. Remove the Printer Cable Plug from the memory console "POWER" Socket.
7. Then insert the ADAM™ Adapter into the memory console "POWER" Socket.
8. Now insert the Printer Cable Plug into the ADAM™ Adapter marked "POWER".
9. Insert the Power Adapter Plug from the Roller Controller unit into the ADAM™ Adapter marked "ACCESSORY."
10. Plug the power cord on the printer into the electrical wall outlet. Now you are ready to begin playing your game! **BE SURE THAT THE COLECOVISION® UNIT IS OFF BEFORE INSERTING OR REMOVING CARTRIDGE.** Refer to your GAME CARTRIDGE Instruction Guide for game play instructions.

**NOTE:** The ADAM™ Adapter does not have to be removed from the ADAM™ Computer Module after using your Roller Controller.



**Fig. 2**